

RAIN GAUGE

Operating Instructions

Product code:

808-145

INSTRUMENT OPERATION - Position the Rain Gauge in an open area to get an accurate reading. When rain falls, the gauge cup will fill (up to a maximum of one litre), allowing the user to record the daily rainfall on the easy to read scale. Noting the amount of rainfall on the scale, empty the contents and turn the revolving ring, to indicate the amount, each time that rainfall is recorded. The rain gauge can be mounted onto a Ø26 mm pole (pole not supplied).



Supplied by

Electronic Temperature Instruments Ltd

Worthing · West Sussex · BN14 8HQ

01903 202151 · sales@etiltd.com · etiltd.com

26.05.21