



THERMA WATERPROOF THERMOMETER (TYPE T)



Operating Instructions

INSTRUMENT OPERATION - Connect probes via the socket(s) located at the top of the instrument. (The Therma Waterproof uses a miniature type T thermocouple connector). Switch the instrument on and apply the tip of the probe to the substance or medium to be measured. The instrument reading may take a few seconds to stabilise, depending on the nature of the measurement and sensitivity of the probe.

HOLD - Press the HOLD button to stop measurements, press again to continue measuring.

AUTO-OFF - The unit will switch off automatically after 10 minutes. To disable auto-off, press the HOLD button whilst switching on the instrument (this is reset when the instrument is switched off).

OPEN CIRCUIT/FAULTY PROBE - If the probe has developed an 'Open Circuit' fault the instrument will display 'Err'.

SENSORS - The Therma Waterproof should only be used with a type T (Copper/Constantan) thermocouple probe (to BS EN 60584-1-2013) fitted with miniature type T thermocouple plug (to BS EN 50212). This instrument is designed to be compatible with ETI manufactured probes.

BATTERY REPLACEMENT - The instrument will display a low battery symbol to warn that the batteries will need changing soon. The instrument continues to measure accurately but after further usage the instrument will display 'flat bat' and shutdown. Replace the three AAA batteries located under the rear case half that is held in place by six screws. Check the seal for damage and carefully replace the rear case half and re-fit and tighten the screws.

MAX/MIN - Press the MAX/MIN button to display the values. The instrument retains the max/min values when switched off. To reset, press the MAX/MIN button for three seconds, 'rst' will be displayed.

BACKLIGHT - Press the HOLD button for two seconds. **Please Note:** the backlight will not operate if the low battery symbol is being displayed. (Backlight timeout = 20 seconds).

TRIM - Press the MAX/MIN and ON/OFF buttons at start-up for five seconds to enter ('Offset' is displayed). MAX/MIN then cycles (continuous loop) the trim value in 0.1 steps up to ± 2.0 °C (3.6 °F). Press ON/OFF to save the value and exit Trim mode.

°C/°F - Press and hold ON/OFF button for five seconds at start-up.

WARNING: IPA and other solvents may cause damage to the case and screen of this instrument.

GUARANTEE - This instrument carries a two-year guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. This guarantee does not apply to probes, where a six-month period is offered. The product guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at etiltd.com. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.

SPECIFICATION - Full specification details of all products are available at etiltd.com.



Manufactured by
Electronic Temperature Instruments Ltd
Worthing · West Sussex · BN14 8HQ
01903 202151 · sales@etiltd.com · etiltd.com



545-171 WEB/30.07.25